

LA01 Fit Over Rx, Laser Alignment Glasses



Fit Over Rx Glasses. Image represents frame style only. Filter color will vary by product specification.

Stock **#17-631** 1 In Stock

-

1

+

€214⁰⁰

ADD TO CART

Volume Pricing	
Qty 1-5	€214,00 each
Qty 6-10	€192,60 each
Qty 11-25	€171,20 each
Need More?	Request Quote

! Prices shown are exclusive of VAT/local taxes

Product Downloads

SPECIFICATIONS

General

Fit Over Rx Glasses

Style:

EN 207/208 Ratings: RB2 @518 - 532 & 533 - 536nm, RB3 @524 - 532nm	
Polymer	Filter Material:
LA01	Filter:
Optical Properties	
Optical Density OD (Average): >5 @ 190 - 400nm >2 @ 518 - 523nm >2 @ 533 - 536nm >3 @ 524 - 532nm	
Topaz	Color:
Visible Light Transmission VLT (%): 47	
Regulatory Compliance	
View	Certificate of Conformance:

PRODUCT DETAILS

- Increased Visibility of Discrete Wavelengths for Laser Alignment
- CE Certified Laser Radiation Protection
- Available in Fit Over Rx Glasses and Adjustable Wrap Around Styles

Laser Alignment Glasses provide a balance of protection and visibility with reduced optical densities at discrete wavelengths compared to [Laser Safety Glasses and Goggles](#), allowing for alignment of visible lasers. These eyewear products feature durable lenses molded with laser-protective absorptive dyes, which prevents surface scratches from affecting lens performance. Multiple lens designs are available that offer alignment beam visibility at Nd:YAG and diode laser lines including 532nm, 561nm, and 650nm. Laser Alignment Glasses are CE certified and come in a protective hard case with an included neck cord and microfiber cloth.

Laser Alignment Eyewear are available in three styles:

Fit Over Rx Glasses: fit over prescription glasses and have side-shields for a wide field of view

Adjustable Temples, Wrap Around Frame Glasses: feature a wrap around design with adjustable temple lengths and angle

Adjustable Bridge, Wrap Around Frame Glasses: feature a wrap around design with an adjustable bridge and comfort fit temples

Warning: Because of the potential for eye damage, the degree of protection required in each circumstance should be determined by the Laser Safety Officer, the industrial hygienist, or the individual responsible for the safety program.